

0800304

https://www.phoenixcontact.com/au/products/0800304

Please be informed that the data shown in this PDF document is generated from our online catalog. Please find the complete data in the user documentation. Our general terms of use for downloads are valid.



Shrink sleeve, Roll, yellow, unlabeled, can be labeled with: THERMOMARK E.SLEEVE, THERMOMARK E.300 (D)/600 (D), THERMOMARK ROLLMASTER 300/600, THERMOMARK ROLL X1, THERMOMARK ROLL, THERMOMARK ROLL 2.0, THERMOMARK W, THERMOMARK X1.2, cable diameter range: 3.2 ... 9.5 mm, unperforated, mounting type: slide-on, cable diameter range (automated processing): 3.2 ... 8.5 mm, Number of individual labels: 1, roll length: 20 m, text field height: 16 mm, text field width: 20000 mm

Product description

The continuous shrink sleeves in the WMS... product family, in size 2.4 ... 9.5, are suitable for automated processing with the THERMOMARK E. SLEEVE applicator. The continuous format of the material means that individual marker lengths can be realized. After the printing and applying process, you have the option of shrinking the marked shrink sleeves by applying heat manually and thus fixing them on the cable/wire.

Your advantages

- · Permanent and captive identification of single-core wires, wires, cables, pneumatic hoses, and other cylindrical objects
- High flexibility, as individual marker lengths ranging from 3.45 mm ... 2000 mm (0.14" ... 78.7") can be realized in combination with the cutter and perforation cutter
- · As an option, the sleeves can be shrunk by applying heat manually to fix the sleeve in position
- High diameter coverage with a shrink ratio of 3:1
- · Widely used and proven worldwide in control cabinet and machine building, the oil and gas industry, and the railway industry

Commercial data

Item number	0800304
Packing unit	1 pc
Minimum order quantity	1 pc
Sales key	BG2216
Product key	BG2216
Catalog page	Page 227 (C-3-2019)
GTIN	4046356626019
Weight per piece (including packing)	329.3 g
Weight per piece (excluding packing)	296.39 g
Customs tariff number	39173200
Country of origin	CN



https://www.phoenixcontact.com/au/products/0800304



Technical data

Notes

Note on application	For the THERMOMARK ROLL and THERMOMARK ROLL 2.0 roll printers, this material can only be processed with an external media hub.
Material information	The specified minimum wire diameter of the shrink sleeve refers to its use as a marking material and does not guarantee any insulation characteristics once shrunk. Depending on the processed material batch, as well as the
	storage and processing conditions, the maximum insertable wire diameter may be reduced.

Product properties

Product type	Shrink sleeve
Туре	Shrink sleeve
Marking	
Number of individual labels	1
Identification technology	Thermal transfer for rolls

Dimensions

Width	16 mm
Length of roll	20.00 m
External dimensions	
Outside diameter	3.2 mm 9.5 mm
Text field	
Text field width	20000 mm

16 mm

Material specifications

Text field height

Color	yellow (RAL 1018)
Material	Polyolefine
Base element material	polyolefine
Shrink rate	3:1
Components	halogen-free
Shrink temperature	> 85 °C

Cable/line

External cable diameter	3.2 mm 9.5 mm
-------------------------	---------------

Environmental and real-life conditions

Test for substances that would hinder coating with paint or varnish



https://www.phoenixcontact.com/au/products/0800304



Result	Test passed
cratch test for the determining scratch resistance	
Specification	EN ISO 1518-1:2023 (following)
Requirements	≥ 5 N
Result	Test passed
rosuit	rest passed
esafilm test	
Specification	DIN EN ISO 2409:2020-12 (following)
Result	Test passed
IV resistance	
Specification	ISO 4892-2:2013-03 (following)
Result	Test passed
Test duration	96 h
'amagazatura rapiatanaa	
emperature resistance	ANCI/II 060 2018:02 (fallowing)
Specification Test duration	ANSI/UL 969-2018:03 (following) 240 h
Rating 125 °C (150 °C)	Test passed
/ipe resistance of inscriptions	
Specification	DIN EN 61010-1 (VDE 0411-01):2020-03
	DIN EN 62208 (VDE 0660-511):2012-06 (in parts)
Isopropyl [CAS No. 67-63-0]	Test passed
n-Hexane [CAS No. 110-54-3]	Test passed
Water + Petroleum ether [CAS No. 64742-82-1]	Test passed
Sodium hydroxide 0.1 mol/l [CAS No. 1310-73-2]	Test passed
Ethanol (99 %) [CAS No. 64-17-5]	Test passed
Acetone (99 %) [CAS No. 67-64-1]	Test passed
Specification	ISO 175:2010 (following)
Test duration	168 h
Sodium hydroxide 0.1 mol/l [CAS No. 1310-73-2]	Test passed
Ethanol (99 %) [CAS No. 64-17-5]	Test passed
Acetone (99 %) [CAS No. 67-64-1]	Test passed
Diesel [CAS No. 68476-34-6]	Test passed
IRM 901	Test passed



0800304

https://www.phoenixcontact.com/au/products/0800304

Mounting type

Specification	EN ISO 22479:2022-06
Result	Test passed
Procedure	Method B
Cycles	2
alt spray test	
Specification	DIN EN IEC 60068-2-11 (VDE 0468-2-11):2022-10
Result	Test passed
Test duration	96 h
mbient conditions	
Ambient temperature (operation)	-55 °C 125 °C
	-55 °C 125 °C 23 °C
	23 °C
Ambient temperature (operation) Recommended ambient temperature (storage/transport)	23 °C 50 % (Storage in a dry and dark place in the original packaging
Ambient temperature (operation) Recommended ambient temperature (storage/transport) Recommended humidity (storage/transport)	23 °C 50 % (Storage in a dry and dark place in the original packaging recommended)

slide-on



0800304

https://www.phoenixcontact.com/au/products/0800304

Approvals

To download certificates, visit the product detail page: https://www.phoenixcontact.com/au/products/0800304



CSA

Approval ID: 252259



cULus Recognized

Approval ID: E310982_Vol2_Sec1



0800304

https://www.phoenixcontact.com/au/products/0800304

Classifications

ECLASS

UNSPSC 21.0

ECLASS-11.0	27281102
ECLASS-12.0	27281102
ECLASS-13.0	27281102
ETIM	
ETIM 9.0	EC001530
UNSPSC	

39131500



0800304

https://www.phoenixcontact.com/au/products/0800304

Environmental product compliance

EU RoHS

Fulfills EU RoHS substance requirements	Yes, No exemptions
EU REACH SVHC	

Phoenix Contact 2025 © - all rights reserved https://www.phoenixcontact.com

PHOENIX CONTACT PTY Ltd Unit 7, 2-8 South Street Rydalmere NSW 2116 1300 786 411 customerservice@phoenixcontact.com.au